


VTR-4000C

Evaluation and Product Development Platform

Quick-Start Guide - Decoder Kit

Revision 1.0



© 2017 SOC Technologies Inc.

Quick-Start Guide

V1.0, 2017

SOC is disclosing this user manual (the "Documentation") to you solely for use in the development of designs to operate with SOC hardware devices. You may not reproduce, distribute, republish, download, display, post, or transmit the Documentation in any form or by any means including, but not limited to, electronic, mechanical, photocopying, recording, or otherwise, without the prior written consent of SOC. SOC expressly disclaims any liability arising out of your use of the Documentation. SOC reserves the right, at its sole discretion, to change the Documentation without notice at any time. SOC assumes no obligation to correct any errors contained in the Documentation, or to advise you of any corrections or updates. SOC expressly disclaims any liability in connection with technical support or assistance that may be provided to you in connection with the Information.

THE DOCUMENTATION IS DISCLOSED TO YOU "AS-IS" WITH NO WARRANTY OF ANY KIND. SOC MAKES NO OTHER WARRANTIES, WHETHER EXPRESSED, IMPLIED, OR STATUTORY, REGARDING THE DOCUMENTATION, INCLUDING ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NONINFRINGEMENT OF THIRD-PARTY RIGHTS. IN NO EVENT WILL SOC BE LIABLE FOR ANY CONSEQUENTIAL, INDIRECT, EXEMPLARY, SPECIAL, OR INCIDENTAL DAMAGES, INCLUDING ANY LOSS OF DATA OR LOST PROFITS, ARISING FROM YOUR USE OF THE DOCUMENTATION.

© 2007-2017 SOC, Inc. All rights reserved.

SOC, the SOC logo, the Brand Window, and other designated brands included herein are trademarks of SOC, Inc.

Revision History

Date (MM/DD/YYYY)	Version	Notes	Author
05/25/2017	1.0	Initial Version	Mulong Li

This document is intended to be a quick-start guide for getting familiar with the evaluation kit environment. For a thorough evaluation of SOC CODEC's capabilities, please refer to the User Guide and various API Manuals after reading this guide.

1. Kit Contents

1. VTR-4000C Decoder Carrier-Board
2. Decoder Module
3. Cables
 - 5V Power Adapter
 - USB Mini-B Cable
 - HDMI and/or SDI cable(s)
 - Ethernet Cable

2. Prerequisites

To avoid issues, please use the latest versions of software.

1. Latest version of VLC Media Player - <http://www.videolan.org>
2. Serial terminal. (Recommended: Tera Term - <https://tssh2.osdn.jp>)
3. (Optional) SOC API CLI Toolkit – <http://soctechnologies.com/tools>

3. Connecting the System

Device	External	Board Port	Notes
HDMI Cable	1080p display	HDMI_OUT(J30)	up to 1080p video output
SDI Cable	up to 2160p(4K) display	Quadrants: SDI_CH1 (J12), upper-left SDI_CH2 (J25), upper-right SDI_CH3 (J19), lower-left SDI_CH4 (J26), lower-right	for 1080p(HD) CODEC module, use SDI_CH4(J26) only
Mini-B USB	PC	USB-UART (J4)	For API access
Module		SODIMM Slot (J2)	Power-off carrier board before inserting/removing modules.

Device	External	Board Port	Notes
Ethernet Cable	PC Ethernet port, SOC decoder board, a network switch, router, or a third-party receiver.	Primary Ethernet port (J5, bottom)	To receive encoded stream data.
5V Power	5V Adapter	5V DC IN (J7)	Power switch: S6

4. Sending Streams

PC to Decoder Kit

Checklist:

- Cables connected (See 3. *Connecting the System*).
 - Ethernet cable connected from board to PC
- Serial terminal with serial port (COM port) open on PC.
 - VLC's destination IP address matches Carrier-board IP. (See *SOC VTR-4000C Carrier Board API Specification*)
- On PC, VLC sending a Transport Stream to “udp://192.168.1.xxx:1234”

Encoder Kit to Decoder Kit

Checklist:

- Cables connected (See 3. *Connecting the System*)
 - Ethernet cable connected from Encoder board to Decoder board.
- Encoder TX IP matches Decoder IP (matches by default).

5. On-board User Interface

	Label	Notes
System Reset	S3 (Push-button)	Reset the carrier board system
API Mode Cycle	S2 (Push-button)	Toggles API Mode (See 6. <i>API Interface</i>)
API Mode LED	D11 (LED)	Off – Carrier Board API On – Module API
SDI LED	D5 D14 D7 D23 (LEDs)	Off – SDI TX/RX signal detected On – No SDI TX/RX signal

Network Speed Select*	J9 0/1 (Jumper)	On/Present - 1Gbps Off/Not Present - 100Mbps
------------------------------	-----------------	---

*: Network Speed can be pre-configured before power-on through Jumper J9, and can be re-configured after power-on using API interface. (See *SOC VTR-4000C Carrier Board API Specification*)

6. API Interface

When the USB-UART Cable is connected from board to PC, the PC will expose a serial (COM) port. You can find this port in Windows in **Device Manager > COM Ports**. Use the following settings for the serial port:

- Baud rate: 115200
- Data bits: 8
- Parity: None
- Stop bits: 1
- Flow control: None

The serial link is shared by the carrier board and the module endpoints, one at a time. The API endpoint can be selected by pressing the API Mode Cycle button S2. API Mode LED D11 indicates the endpoint that is currently linked.

Endpoint	API Functions Available	Documentation
Carrier Board API	<ul style="list-style-type: none"> • Network Configuration (send/receive IP/port) • Flash Update 	<ul style="list-style-type: none"> • VTR-4000C API Manual
Module API	<ul style="list-style-type: none"> • CODEC Core API • CODEC System API • Flash Update 	<ul style="list-style-type: none"> • H.264 Decoder API Manual • H.265 Decoder API Manual (coming soon) • Decoder System API Manual • Multiboot Module API Manual

The API serial format is available in two formats. You may press ESC (or ENTER without entering a value) to cycle the prompt. **Important: Backspace is not supported.** If you make a mistake, use ESC to cycle back and restart the input.

New API 2.0 format

Format: (optional arguments: [optional])**C AA [DDDD]**

- C = Command (R/r/W/w)
- AA = 2 Byte Hex Address
- DDDD = 4 Byte Hex Data Value

Read a register value:

> R <address hex>

Change a register value:

> W <address hex> <value hex>

Legacy API 1.0 format

Legacy API prompt looks like this: **“Enter an address(HEX):”**

The API will expose an address-value prompt-loop. To change values, enter the register address at the address prompt (in hex), and then the decimal value at the value prompt, followed by enter. Hex values are also accepted when given an “h” prefix/suffix, (ex. 4ABCh or h4ABC represent 0x4ABC)

You can safely press **ESC** at any time to cycle the prompt without changing current values.